

CAN OPENER

SPECIFICATION

Material: ABS

Net weight: 69g

Size: 10*6.8*1.7cm

FEATURES

Function: Can opener is a tool designed to remove the top of almost any can.

Safe open: The innovative design safely removes the top

Enjoy the full taste: By removing the entire top, it allows your nose to enjoy the fragrance of your beverage.

PACKAGE INCLUDES

1 x Can Opener

HOW TO USE

- Grasp the can.
- Pull the handle of the can opener out.
- Place the can opener on the top of the can.
- Align the edge, squeeze the handle and slowly turn.



KEEP IT AWAY FROM KIDS!!!

